

## Swivel iPad Clamshell Attachment

**Connectors**

**iPad Mount**

Slide connectors into groove of extrusion. Tighten setscrew to secure in place. Attach monitor mount to connectors with screws.

**Swivel Mounting Plate**

**Hex Nuts**

Bolt iPad clamshell to mounting plate with hex nuts.

**Lock**

**Lock**

**iPad**

**Wire Access**

**Clam Shell rotates between portrait and landscape modes.**



Side view




Landscape Mode



Portrait Mode

### Optional Cover for Home Button



- 1) Remove foam lining from inside bottom of clam shell as shown.
  - 2) Attach Home Button Shield with double-sided tape to inside of clam shell, keeping top of shield flush with clam shell opening as shown.
- NOTE:** This is a permanent fix and can't be easily removed.

**WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING**